

Wooden Shoe Sizes

This is only a guide. The best way to fit the shoe is to measure
your foot in CM. Add 1/2 to 1 cm to that number for your size.

			Wooden Shoe Size (CM)
Children	Women	Men	
3			12
4-5			13
6-7			14
7-8			15
8-9			16
10			17
11-12			18
12-13			19
	1		20
	2-3		21
	3-4		22
	5-6	5	23
	7	6	24
	8	7	25
	9	8	26
	10	9	27
	11	10	28
	12	11	29
	13	12	30
		13-14	31
		15	32
European Size Conversion			European Size
	2 - 2 1/2		33
	3 - 3 1/2		34
	4 - 4 1/2		35
	5 - 5 1/2		36
	6 - 6 1/2		37
	7 - 7 1/2	5 - 5 1/2	38
	8 - 8 1/2	6 - 6 1/2	39
	9 - 9 1/2	7 - 7 1/2	40
	10 - 10 1/2	8 - 8 1/2	41
	11 - 11 1/2	9 - 9 1/2	42
	12 - 12 1/2	10 - 10 1/2	43
		11 - 11 1/2	44
		12 - 12 1/2	45
		13 - 13 1/2	46
		14 - 14 1/2	47